MyBar.io

1. Introduction

Written By: MyBar.io



Step 1 — Required tools



- 2mm Allen key
- Phillips Screwdriver (Not Included)
- i No soldering is required.
- (i) No wire crimping is required.
- Ready to start? Go to <u>2. Electronics</u>